



NOTES:

1. TO ASSEMBLE, APPLY A DOUBLE LAYER OF TEFLON TAPE, AND A LAYER OF PIPE DOPE TO THE THREADS ON THE PLASTIC FITTINGS AND INSTALL PER THE MANUFACTURER'S INSTRUCTIONS. (FOR SS FITTING INTO SS THREAD, USE PIPE DOPE OR TEFLON TAPE, NOT BOTH.)
2. ASSEMBLY IS TO BE PRESSURE TESTED.
3. ASSEMBLY IS TO BE USED WITH SDR11 HDPE PIPE.



TOWN OF NORTH ATTLEBOROUGH, MASSACHUSETTS
DEPARTMENT OF PUBLIC WORKS

Date Last Updated:
03/03/2023

LOW PRESSURE SEWER-LATERAL KIT DETAIL PT.2

N.T.S.

Detail Number:
S-7.4